

Assembly, Operating & Maintenance Instructions

buroseating


Attention: Please remove all items from the carton, and verify all pieces before assembly.


BURO FORCE CHAIR (Optional arms)





Parts List		
KEY	QTY	DESCRIPTION
Α	1	Backrest
В	1	Seat
С	1	Base
D	5	Castors
Ε	1	Gaslift
F	1	Mechanism
G	2	Armrests (optional)
Н	4	Screws (M6 35mm)
	6	Screws (M6 45mm)
J	3	Screws (M8 20mm)
K	6	Washers (M8 Ø 17mm)
L	6	Spring Washers (M8 Ø 14x2mm)









Care & Maintenance

GENERAL CARE

- To maintain the appearance of non-upholstered parts wipe the surface with a clean cloth dampened with a mild detergent solution.
- Do not remove any parts for separate cleaning.
- Do not saturate the fabric or interior with water or other cleaning liquids.
- Do not shampoo clean.
- $\boldsymbol{\cdot}$ Do not clean with hot water extraction machine.
- $\boldsymbol{\cdot}$ Do not clean with onsite drycleaning machine.
- Protect from direct sunlight, heat and weather.

FABRIC UPHOLSTERY CARE

- Wipe with a clean cloth dampened with a mild upholstery detergent solution.
- A soft bristle brush may be used to remove ingrained soil.
- · Spot clean as above.
- · Treat spills and stains as soon as possible.
- Persistent stains may require treatment by a professional cleaner.
- · May be cleaned with dry powder cleaners.
- · Allow to dry thoroughly before reuse.

Upholstery & Foam Specs*

FOAM

Flame Resistant: Ca117 Section A Part I & Section D Part II

UPHOLSTERY: FABRIC

Flame Resistance: Ca117 Section E Class I

*This applies only to standard Buro Seating stock. Any customer specified upholstery may not meet these specifications.

Preventative Maintenance & Warning!

- · Use this product only for seating one person at a time
- Do not use this chair as a step stool/ladder
- Do not sit on any part of the chair except the seat.
- Do not use this chair on uneven floor surfaces.
- Do not interfere with the operating of the gas lift.
- Do not use chair unless all bolts, screws and knobs are tight.
 At least every six months check all bolts, screws and knobs to ensure they are tight.
- If any parts are missing, broken, damaged or worn do not use the product until repairs are made using factory authorised parts.
- · Dispose of packaging properly.
- · Plastic bag is not a toy.
- Do not use plastic bag as a head covering as it may cause suffocation.
- Failure to follow these warnings could result in serious injury.

